
## Wiring Instructions for PCU (R4 Mortise)



**Note:** When mode is switched (from FS to FSE or FSE to FS) the lock requires a complete lock/unlock power cycle to synchronize to the proper mode.