

TEMPLATE FOR ED6500

IMPORTANT : ATTACH STRIKE TO FRAME OR MULLION BEFORE POSITIONING TEMPLATE ON DOOR, LOCATE TEMPLATE FROM SURFACE OF STRIKE.

