

# INSTALLATION INSTRUCTIONS for THUMBPIECE TRIM

Page 1 of 1

Entrance ANSI Function 08	Passage ANSI Function 14	Dummy ANSI Function 02	PROPER OPERATION REQUIRES STOREROOM FUNCTION CAM, ORDERED SEPARATELY Storeroom ANSI Function 03
<p>Lockable Trim Plate. Key locks and unlocks Trim.</p> <p>ATTACH THE COLLAR AND MORTISE CYLINDER TO THE TRIM PLATE WITH THE MORTISE NUT. ATTACH TRIM TO DOOR THRU BOLTING (2) SCREWS TO THE CHASSIS &amp; THE (2) CUP WASHERS AND SCREWS AT THE TOP &amp; BOTTOM TO THE DOOR.</p>	<p>NO cylinder, Trim always operable.</p> <p>ATTACH TRIM TO DOOR THRU BOLTING THE (2) SCREWS TO THE CHASSIS &amp; (2) CUP WASHERS AND SCREWS AT THE TOP &amp; BOTTOM TO THE DOOR.</p>	<p>Pull trim only. Used with dogged down device.</p> <p>ATTACH TRIM TO DOOR THRU BOLTING THE (2) SCREWS TO THE CHASSIS &amp; (2) CUP WASHERS AND SCREWS AT THE TOP &amp; BOTTOM TO THE DOOR.</p>	<p>Always locked. Key unlocks Trim Plate.</p> <p>ATTACH THE COLLAR AND MORTISE CYLINDER TO THE TRIM PLATE WITH THE MORTISE NUT. ATTACH TRIM TO DOOR THRU BOLTING (2) SCREWS TO THE CHASSIS &amp; THE (2) CUP WASHERS AND SCREWS AT THE TOP &amp; BOTTOM TO THE DOOR.</p>

※ Tailpiece can be cut to proper length for fitting.