



PUSH PULL LOCK MOUNTING INSTRUCTIONS

1. CUT DOOR PER TEMPLATE
2. MOUNT MORTISE IN CUTOUT
3. INSTALL SPINDLES INTO MORTISE HUBS- 1 END OF THE SPINDLE SCREWS INTO THE OTHER SPINDLE TO HOLD SPINDLES IN PLACE AT THE HUBS. HAND TIGHTEN SCREW AND DO NOT OVER TIGHTEN. SEE FIG 1
4. LINE UP MOUNTING PLATES (HORIZONTAL OR VERTICAL MOUNTING) AND INSTALL USING THE MOUNTING POSTS (2) AND MOUNTING SCREWS (2).
5. PLACE LEVER ASSY ON MOUNTING PLATE AND INSTALL USING THE MOUNTING PLATE SCREWS (4 PER LEVER ASSY). INSTALL COVER OVER LEVER ASSEMBLY AND FASTEN WITH THE 2 COVER SCREWS.
6. FUNCTIONALLY CHECK LOCK TO ENSURE LEVERS (PUSH OR PULL) OPERATE THE MORTISE LOCK PROPERLY. IF THERE IS SOME BINDING YOU MAY NEED TO ADJUST THE ALIGNMENT OF THE MOUNTING PLATE.
7. PUT COVER OVER LEVER ASSY AND SECURE WITH THE COVER SCREWS (2 PER COVER).

WARNING: ENSURE LOCK OPERATES PROPERLY BEFORE LOCKING



NOTES:

<h1 style="margin: 0;">TownSteel</h1> <p style="margin: 0;">17901 RAILROAD STREET CITY OF INDUSTRY, CA 91748</p>	DRAFT UNLESS OTHERWISE SPECIFIED: 1° MAX	TOLERANCES UNLESS OTHERWISE SPECIFIED: X.X (METRIC) = ±0.4 X.XX (METRIC) = ±0.15 FRACTIONS = ±0.03 ANGLES = ±1/2° © .12 MACHINED SURFACES 125/	MATERIAL: N/A
	DRAWN BY: SC		HEAT TREAT: N/A
	DATE: 7/25/14	THIRD ANGLE	FINISH: PER ORDER
			TITLE: ASSEMBLY INSTRUCTIONS PUSH-PULL LEVER
			PART#: PUSH PULL INSTR

THIS DRAWING AND THE INFORMATION CONTAINED THEREON OR DERIVED THEREFROM ARE THE CONFIDENTIAL PROPERTY OF TOWNSTEEL, INC. IT IS NOT TO BE REPRODUCED, OR DISCLOSED TO OTHERS, AND MAY BE USED ONLY FOR THE PURPOSE OF ENABLING THE PARTY TO WHOM IT HAS BEEN LOANED TO QUOTE ON OR FILL AN ORDER FOR TOWNSTEEL, INC., OR AS MAY BE OTHERWISE AUTHORIZED BY TOWNSTEEL, INC. IN WRITING.